

Honda Accord 2004 – 2007




****READ THIS FIRST****

Changing Sources (iPod, HD Radio, *Satellite radio, Aux)

- Press the AM/FM button
- Press the CD/AUX/XM button
- Press the Tune > button until the source you want is displayed
- Press Preset 6 to select the source

*if available



Browsing Example:

To select the song "Star-Spangled Banner" through the Artist category

Press Preset 6 to enter into the browse menu. The radio will display "PL:LIST"

Press the TUNE >> button until radio displays "AR:ARTIST". Press Preset 6 to select. Radio will display "AR:ALL"

Press the TUNE >> button until radio displays "AR:Francis Scott Key". Press Preset 6 to select. Radio will display "AL:ALL"

Press the TUNE >> button until radio displays "AL:Patriot Hits Vol. 1". Press Preset 6 to select. Radio will display "TR:ALL".

Press the TUNE >> button until radio displays "TR:Star-Spangled Banner". Press Preset 6 to select. Song will begin to play and display will show track info.

(Actual Radio Appearance may differ from representation.)

Honda

Accord 2004 – 2007




****READ THIS FIRST****

Changing Sources (iPod, HD Radio, *Satellite radio, Aux)

- Press the AM/FM button
- Press the CD/AUX/XM button
- Press the Tune > button until the source you want is displayed
- Press Preset 6 to select the source

*if available



HD RADIO EXAMPLE

To select an HD radio station.

Press the SEEK ►► button to get to the desired station. The Radio will auto lock on to an HD Radio Station if available; example: 92.5 HD1 MHZ. When locked into an HD Radio Station, press the SEEK ►► button to access multi-cast HD Station(s) (if available); example: 92.5 HD2 MHZ

To store a radio station into preset memory.

Press and hold any preset (1-6) to store a station into memory. The screen will display "PR:SAVED"

To recall a station stored into preset memory.

Press and release the desired preset that you wish to recall.

(Actual Radio Appearance may differ from representation.)